

# BIKEBONZ COMPONENTS


## KTM Axle Pull

2003 - 2008


MADE IN CANADA

### INSTALLATION INSTRUCTIONS: PLEASE READ!!!

1. Remove threaded axle nut.



2. Place a punch/bar long enough to reach thru the axle and knock out the axle cap by striking the punch/bar with a hammer.




3. If you have a press, remove axle and press axle pull into axle until seated.

4. If you do not have a press, do not remove axle. Set the axle pull squarely into the end of the axle. Place a block of wood over the end of the axle pull, making sure to keep square to the axle.



5. Strike the block of wood with a hammer until the pull is seated, it may take several blows.

6. Reinstall the axle nut.



Forward any comments to [sales@bikebonz.com](mailto:sales@bikebonz.com)

**WWW.BIKEBONZ.COM**