



Keihin "FCR" T-Handle Mixture Screw

 **MADE IN CANADA**



INSTALLATION INSTRUCTIONS:

Remove stock fuel screw.

IMPORTANT!!! Be careful when removing the fuel screw.

There is a small washer and o-ring that sit on top of the mixture screw spring. **Do not loose!**

Place spring, washer and o-ring on your new mixture screw.

Engine should be warm set idle to 1400 - 1500 rpm by turning the idle adjust wheel.

Set mixture screw out 1 ½ turns from seated.

Turn T-handle in clockwise until the engine rpm starts to slow.

Note position. _____

Turn T-handle out counterclockwise until the engine rpm starts to slow.

Note position. _____

Set mixture screw at the highest idle between the low idle points.

Note: If you are unable to reach a low idle point adjusting the mixture screw out, then a larger Pilot Jet may be required.

Note: If you are unable to reach a low idle point adjusting the mixture screw in, then a smaller Pilot Jet may be required.

Forward any comments to sales@bikebonz.com

WWW.BIKEBONZ.COM