



PRODUCT INSTALLATION

HAND GUARD MOUNTS

MADE IN CANADA

PLEASE READ!!!

Thank you for purchasing Bonz Hand Guard Mounts. Bonz mounts have been designed to accommodate a large range of applications. Due to variations in bar length, rise and variations in hand guard length and bends, some tweaking of the hand guards may be required to obtain a perfect fit.

INSTALLATION INSTRUCTIONS:

- 1) Remove Top bar clamps. Install Bonz Hand Guard Mounts and tighten bolts evenly.**
- 2) Modify throttle assembly.** Loosen throttle assembly and move towards end of bar. With a razor knife, cut end of grip so the entire end is missing. Use a hacksaw to saw off the end of the throttle tube. Remove the end from the left grip with the razor knife.
- 3) Fit hand guards.** Hold your hand guards in position and note fit. If your hand guards appear too short, open the bend in the hand guards slightly. A little tweak goes a long ways. If the hand guards are too long, close the bend slightly.
NOTE: If your hand guards have holes for deflectors be careful not to bend at the holes, the weakest point. Hold hand guards in a way that you are bending in the area without holes.
- 4) Install hand guards.** Install bar end bolts, do not tighten. Align mounting holes to the Bonz mounts, install bolts. Tighten all bolts and go ride!



Tools; Allen Wrenches, Hacksaw, Razor Knife.

For more information contact us at sales@bikebonz.com

HAND GUARD ADJUSTMENTS

LONGER

SHORTER

